




RPS series**PIN SOCKET CONNECTOR for RPCB-4B****RPS dimensions**

■ DXF/DWG/PDF drawings available on our website.

RPS2-2



RPS2-20



■ Material / Color : (Socket) FRPBT UL94V-0 /Black • (Pin) Phosphor bronze



■ 2.54mm hole-to-hole pitch pin socket connector.
Utilize with RPCB-4B expansion PCB for Raspberry Pi 4B.

Product no.

Product no.	Pin layout	Pack of
RPS2-2	4 (2 pin x 2)	1
RPS2-20	40 (20 pin x 2)	1

RPSP2.5-11**HEXAGONAL SPACER****RPSP2.5-11 dimensions**

■ DXF/DWG/PDF drawings available on our website.



■ Material / Finish : Brass / Nickel plated

■ Brass hexagonal spacer with M2.5 threads on both male and female sides.
Utilize with RPCB-4B expansion PCB for Raspberry Pi 4B.

Product no.

Product no.	Pack of
RPSP2.5-11	4


MT2.5-4**MOUNTING SCREW for RPSP2.5-11****MT2.5-4 dimensions**

■ Material / Finish : Steel / Trivalent chromate


■ Utilize when affixing RPCB-4B expansion PCB.

Product no.

Product no.	Pack of
MT2.5-4	4

RPCB-4B**EXPANSION PCB for Raspberry Pi 4B**

Installation example



■ Material / Finish : Glass epoxy (FR-4) / Through-hole - Lead-free solder resist

■ Expansion PCB for standard Raspberry Pi 4B boards. Use to install expansion parts or components.


■ Environmentally friendly lead-free solder. RoHS3 compliant.

■ Raspberry Pi Board is not included.

■ Connector, spacer, and mounting screw set are sold separately.

RPCB-4B dimensions

■ DXF/DWG/PDF drawings available on our website.

**Product no.**

Product no.	Pack of
RPCB-4B	1

■ Expansion PCB can also be utilized on RPI-4B and RPA series cases.

See page 132 ~ 134 for RPI series case and page 135 ~ 136 for RPA series case.

